


NOTE 1: SOME OF THE CIRCUITS SHOWN HERE WILL NOT BE ACTIVE IN ALL APPLICATIONS. CONSULT THE EQUIPMENT MANUFACTURER'S LITERATURE TO DETERMINE WHICH CIRCUITS ARE USED.


NOTE 2: MAY BE EITHER INCREMENT OR DECREMENT DEPENDING ON THE VALUE OF THE ECM ADJUSTABLE PARAMETER "CRUISE CONTROL SETUP".

OEM RESPONSIBILITY


ELECTRONIC CONTROL MODULE (ECM) OEM CONNECTOR



9-PIN DEUTSCH CONNECTOR




OEM POWER CONNECTOR




CUMMINS RESPONSIBILITY


ELECTRONIC CONTROL MODULE ENGINE HARNESS CONNECTOR




ROCKER LEVER COVER GASKET-INJECTOR PASS-THROUGH




ROCKER LEVER HOUSING-INJECTOR PASS-THROUGH




















ELECTRONIC CONTROL MODULE (ECM)



ELECTRONIC CONTROL MODULE (ECM) ENGINE HARNESS CONNECTOR MATING FACE



ELECTRONIC CONTROL MODULE (ECM) OEM HARNESS CONNECTOR MATING FACE



PROOF COPY

Bulletin 4022080-01  
6/29/2010